

## 398, 399, 400, 401, 402, 407 PVC Carpet/Tile Dividers



### Installation Instructions

1. Cut threshold to size required.
2. Notch around door frame if desired.
3. Apply solid beads of adhesive to underside of threshold legs, so when set in place the adhesive spreads to thinly cover base of all legs.

**NOTE:** Adhesive must be a type designed to bond PVC, concrete, wood, metal or other material to which threshold is being applied. NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this threshold.

4. Affix threshold to desired location.

**IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO THRESHOLD FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.**



POSITIVE PRESSURE TESTED GASKETING MATERIALS  
FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS  
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS  
RATED UP TO 1-1/2 HOURS.  
CATEGORY J