

**398, 399, 400,
401, 402, 407
PVC Carpet/Tile Dividers**



WARNING: These products can expose you to chemicals including DEHP Plasticizer, which is known to the State of California to cause cancer and/or developmental and reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Installation Instructions

1. Cut threshold to size required.
2. Notch around door frame if desired.
3. Apply solid beads of adhesive to underside of threshold legs, so when set in place the adhesive spreads to thinly cover base of all legs.

NOTE: Adhesive must be a type designed to bond PVC, concrete, wood, metal or other material to which threshold is being applied. NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this threshold.

4. Affix threshold to desired location.

IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO THRESHOLD FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.



POSITIVE PRESSURE TESTED GASKETING MATERIALS
FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS
RATED UP TO 1-1/2 HOURS.
CATEGORY J

**398, 399, 400,
401, 402, 407**
Separador de PVC para alfombra/baldosa



ADVERTENCIA: Estos productos pueden exponerlo a productos químicos incluyendo el plastificante DEHP, que el estado de California considera causante de cáncer y/o daños al desarrollo y al sistema reproductivo. Para mayor información visite la página www.P65Warnings.ca.gov.

Instrucciones de Instalación

1. Corte el umbral a la medida.
2. Haga una ranura alrededor del marco de la puerta si lo desea.
3. Aplique líneas de adhesivo a la parte inferior de las patas del umbral para que cuando se instalen el adhesivo se extienda en una capa delgada que cubre toda la base de las patas.

NOTA: el adhesivo debe ser apropiado para pegar PVC, concreto, madera, metal u otro material en el que se instale el umbral. El adhesivo de silicón negro #RR-5007BL de NGP está diseñado específicamente para usarse en la instalación de este umbral.

4. Coloque el umbral en el lugar deseado.

NOTA IMPORTANTE: NO EJERZA PRESIÓN NI CAMINE SOBRE EL UMBRAL DURANTE LAS PRIMERAS 24 HORAS, PARA PERMITIR QUE EL PEGAMENTO CURE COMPLETAMENTE.



MATERIAL DE EMPAQUE PARA PUERTAS CORTAFUEGO
SOMETIDOS A PRUEBAS DE PRESION POSITIVA, PARA
USARSE EN PUERTAS METALICAS HUECAS CORTAFUEGO,
CERTIFICADAS HASTA 3 HORAS Y PUERTAS DE MADERA
CORTAFUEGO, CERTIFICADAS HASTA 1-1/2 HORAS
CATEGORIA J