



Interlocking Rubber Ramp



- Black Rubber
- BHMA Certified to ANSI/BHMA A156.21
1,000 Lb. Load Test
- Supplied With Beveled Ends - (End Slope = 1:2).
Specify if Straight Cut is Required
- Rubber Ramp Sections May Be Combined



ngp.com
1-800-NGP-RUSH

FAX: (800) 255-7874
QUOTES: QUOTES@NGP.COM
ORDERS: ORDERS@NGP.COM

INSTALLATION INSTRUCTIONS

- 1. Ramp may be cut in field to fit floor conditions.
- 2. Apply a solid bead of adhesive to underside of ramp at perimeter edges. Then apply several beads of adhesive in a criss-cross pattern to underside of ramp, so when set in place the adhesive spreads to thinly cover entire underside of ramp.

NOTE: Adhesive must be a type designed to bond rubber, concrete, wood, metal or other material to

which ramp is being applied. (NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this rubber ramp.)

- 3. Affix Rubber Ramp to desired location.

IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO RUBBER RAMP FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.



NGP MEMPHIS
4985 East Raines Road
Memphis, TN 38118

FAX: (800) 255-7874
QUOTES: quotes@ngp.com
ORDERS: orders@ngp.com

CARSON CITY
3689 Arrowhead Drive
Carson City, NV 89706

