

Pile Perimeter Seals

Installation Instructions

1. Cut seal to fit.
2. Position seal and mark screw holes.
3. Drill pilot holes for screws using a 7/64" drill bit.
4. Slightly compress sealing material and place against door.
5. Install with screws provided in all mounting holes, working from one end to the other.
6. Adjust seal to insure door closes and latches properly.

**APPLICATION WARNING:
DO NOT DRILL THROUGH GASKETING MATERIAL.
DRILL BIT WILL DAMAGE MATERIAL.**

Instrucciones de Instalación

1. Corte el sello a la medida.
2. Coloque el sello y marque los orificios para los tornillos.
3. Taladre los orificios guía para los tornillos usando una broca de 7/64".
4. Comprima ligeramente el sello y colóquelo contra la puerta.
5. Instale con los tornillos suministrados en todos los orificios de montaje, procediendo de un extremo a otro.
6. Ajuste el sello para asegurarse que no impida cerrar y correr debidamente el pasador.

**PRECAUCIÓN AL INSTALAR:
NO TALADRE A TRAVÉS DEL EMPAQUE.
LA BROCA DAÑARÁ EL MATERIAL.**



GASKETING MATERIALS FOR FIRE DOORS
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS
RATED UP TO 1-1/2 HOURS.

MATERIAL DE EMPAQUE PARA PUERTAS CORTAFUEGO, PARA
USARSE EN PUERTAS METALICAS HUECAS CORTAFUEGO,
CERTIFICADAS HASTA 3 HORAS Y PUERTAS DE MADERA
CORTAFUEGO, CERTIFICADAS HASTA 1-1/2 HORAS.