



## **INSTALLATION INSTRUCTIONS**

# **185P 170P**

## **Pile Perimeter Seals**

1. Cut seal to fit
2. Position seal and mark screw holes.
3. Drill pilot holes for screws using a  $\frac{7}{64}$ " drill bit.
4. Slightly compress sealing material and place against door.
5. Install with screws provided in all mounting holes, working from one end to the other.
6. Adjust seal to insure door closes and latches properly.



**ngp.com**

**1-800-NGP-RUSH**

FAX: (800) 255-7874

QUOTES: [quotes@ngp.com](mailto:quotes@ngp.com)

ORDERS: [orders@ngp.com](mailto:orders@ngp.com)

### **NGP MEMPHIS**

4985 East Raines Road

Memphis, TN 38118

### **CARSON CITY**

3689 Arrowhead Drive

Carson City, NV 89706