



# RR952

Interlocking Rubber Ramp  
6" Wide x 1/2" Tall



- ▶ Black Rubber
- ▶ 6" Wide x 1/2" Tall
- ▶ BHMA Certified to ANSI/BHMA A156.21 1,000 Lb. Load Test
- ▶ Supplied With Beveled Ends - (End Slope = 1:2). Specify if Straight Cut is Required
- ▶ Rubber Ramp Sections May Be Combined With Aluminum Ramp Components for Higher

Rises, or With 6" Flat Aluminum Interlocking Threshold #957 for Offset Conditions

- ▶ Black Silicone Adhesive Available to Secure Ramps Without Fasteners. Specify RR5007BL, Each Tube Will Secure 2 Ramps 12" Wide x 36" Long (6 Square Feet)
- ▶ Weight: 1.0 Lbs. /Ft.
- ▶ Maximum Length = 120"



[ngp.com](http://ngp.com)  
1-800-NGP-RUSH

FAX: (800) 255-7874  
QUOTES: [QUOTES@NGP.COM](mailto:QUOTES@NGP.COM)  
ORDERS: [ORDERS@NGP.COM](mailto:ORDERS@NGP.COM)

# THRESHOLD

---

# INSTALLATION INSTRUCTIONS

---

1. Ramp may be cut in field to fit floor conditions.
2. Apply a solid bead of adhesive to underside of ramp at perimeter edges. Then apply several beads of adhesive in a criss-cross pattern to underside of ramp, so when set in place the adhesive spreads to thinly cover entire underside of ramp.

**NOTE:** Adhesive must be a type designed to bond rubber, concrete, wood, metal or other material to which ramp is being applied. (NGP black silicone adhesive #RR-5007BL is specifically designed for use to install this rubber ramp.)

3. Affix Rubber Ramp to desired location.

**IMPORTANT NOTICE: DO NOT WALK ON OR APPLY WEIGHT TO RUBBER RAMP FOR 24 HOURS ALLOWING ADHESIVE TO FULLY CURE.**



**NGP MEMPHIS**  
4985 East Raines Road  
Memphis, TN 38118

FAX: (800) 255-7874  
QUOTES: [quotes@ngp.com](mailto:quotes@ngp.com)  
ORDERS: [orders@ngp.com](mailto:orders@ngp.com)

**CARSON CITY**  
3689 Arrowhead Drive  
Carson City, NV 89706

